

### **Overview**

# Lexan film fastener Type 2 - PU = 100 pcs

Product number: 68100300



#### **Options**

#### Version

Type 1 - Buttom

Type 1 - Top

Type 1 - complete

Type 2 - Complete

Type 2 - Top

Type 2 / Buttom







## Description

Our film fasteners are applied for attaching a bubble wrap as an additional isolating material to greenhouse walls (glass or twin-wall sheets).

Bubble wrap is impaled onto the bottom part of the film fastener previously sticked with <u>silicon</u> onto the wall. Afterwards the upper part of the film fastener is screwed up from above to firmly fix the bubble wrap.

#### Created at 27.06.2025.



Fiberlane LLC - 9254 Richmond Road - 18013 Fax.: +1 610 498 2602

Bangor, PA

Tel.: +1 610 498 447 4

email:

info(at)fiberlanellc.com

The upper part of the film fastener can easily be unscrewed to be newly applied during winter seasons.